

# DT 200

## Data Terminal Operators Manual

Version 1.E 03/15/2010  
Program S200001x



Industrial Data Systems, Inc.  
3822 E. La Palma Ave. Anaheim Ca. 92807  
Tech Support 714-921-1353

Website: [www.industrialdata.com](http://www.industrialdata.com)

Email: [Sales@industrialdata.com](mailto:Sales@industrialdata.com)

# Table of Contents

<b>Introduction</b> .....	<b>1</b>
What's In Each Section.....	1
WARRANTY INFORMATION.....	3
<b>General Description</b> .....	<b>4</b>
DT200 Display and Keyboard Diagram.....	4
The DT200 Display.....	4
The DT200 Keyboard.....	5
Numeric Keypad.....	5
Function Keys.....	5
Control Keys.....	5
<b>Installation and Setup</b> .....	<b>6</b>
Unpacking the DT200.....	6
Item check list.....	6
Installation Guide.....	6
Connect DT200 to weight indicator (optional).....	6
Connect DT200 to the printer (optional).....	6
Connect DT200 to host device (optional).....	6
Apply AC Power to the DT200.....	7
Setup Guide.....	7
Initialize to Factory Defaults.....	7
<b>Using the DT200</b> .....	<b>8</b>
Keyboard Layout.....	8
Operation of Function Keys.....	8
Tare.....	8
Gross/Net.....	9
Print.....	9
F1 and F2.....	9
Memory Register Entry.....	9
Execute a Scale Basic Function.....	9
Display Time/Date.....	9
<b>Built In Application Programs</b> .....	<b>10</b>
#1 Fill to Setpoint.....	11
Installation.....	11
Setup Parameters:.....	11
Operators Functions.....	11
# 2 Checkweigh: Under/Between/Over.....	12
Installation.....	12
Operators Functions.....	12
# 3 Weigh-in / Weigh-out.....	13
Weigh-In.....	13
Weigh-Out.....	13
Print ID's, Display ID's, Clear Totals, Erase ID's.....	13
Set Beginning Sequence Number.....	14
Options.....	14
Notes.....	14

# 4 Axle Weigh – Short Scale .....	15
Installation.....	15
Setup Parameters.....	15
Operators Functions .....	15
# 5 Axle Weigh – Long Scale, Unattended .....	16
Installation.....	16
Setup Parameters.....	16
Operators Functions .....	16
# 6 ID, Tare, and Total .....	17
<b>Set Operation Parameters .....</b>	<b>19</b>
Access Operation Parameters and Parameter Functions .....	19
Operation Parameters Reference Tables .....	19
Scale Parameters .....	20
I/O Port Parameters.....	20
Display Intensity, Battery, Watchdog Timer .....	21
Fixed Setpoints.....	21
Keyboard Events .....	21
Parameter Functions .....	22
Scale Parameters.....	22
Parameter 10. Primary Units Type (1 [lb]).....	23
Parameter 11. Decimal Point Position (0 [no decimal point]).....	23
Parameter 12. Count-by (1).....	23
Parameter 13. Alternate Units Type (2 [kg]).....	23
Parameter 14. Alternate Decimal Point (1).....	23
Parameter 15. Alternate Count-by (5).....	24
Serial I/O Ports.....	24
Parameter 23 Serial Com. Port 1 Mode (4 [8 data bits, no parity]) .....	24
Parameter 24 Serial Com. Port 1 Baud Rate (1 [9600 baud]).....	24
Parameter 25 Serial Com. Port 2 Mode (4 [8 data bits, no parity]) .....	25
Parameter 26 Serial Com. Port 2 Baud Rate (1 [9600 baud]).....	25
Parameter 27 TX2 Control / Station ID (255 [single station]).....	25
Parameter 28 TX2 Format (2 Condec format).....	25
Printer Parameters .....	26
Parameter 29 Printer Port Select (2 [Serial Port 1]) .....	26
Parameter 30 Auto Print LF after CR (1 [yes]) .....	27
Parameter 31 End of Print Character (12 [form feed]) .....	27
Parameters 32, 33 34, 84, 85, 86, 87, 88, 89 and 90 Print Labels .....	27
Parameters 35, 36, 37, and 38: Print Codes .....	27
Parameter 39 Enable TTL Remote Control (1 [enabled]) .....	27
Battery, Watch Dog Timer.....	28
Parameter 41 Battery Backup (0 [no]) .....	28
Parameter 42 Enable Watch Dog Timer (0 [no]).....	28
Parameters 43-50 Fixed Registers .....	28
Parameters 51-58 Keyboard Event Functions .....	28
<b>Parameter Functions .....</b>	<b>29</b>
Parameter Functions.....	29
Access Parameter Functions .....	30
Function 59 Display Calibration Audit Number .....	30
Function 64 Configure Passwords .....	31
Function 65 Configure Print Formats.....	31
Modify or Design a Print Format.....	32
Function 66 Set Time and Date .....	36
Function 67 Display Operation Parameters.....	36

Function 68 Print Operation Parameters .....	36
Function 69 Diagnostic Tests.....	36
Function 70 Initialize Operation Parameters to Factory Defaults .....	37
Function 71 Configure Event Monitor .....	37
Function 72 Scale Basic Function Editor .....	37
Function 73 Initialize Function Memory .....	38
Function 74 Configure Timers.....	38
Parameter 76 Debug mode for Event monitors and Scale Basic .....	38
Function 78 Initialize ID memory.....	38
Parameters 91, 92, 93: Serial Port 3.....	38
Parameter 91 Serial Port 3 Mode (4 [8 data bits, no parity]) .....	39
Parameter 92 Serial Port 3 Baud Rate (1 [9600 baud]) .....	39
Parameter 93 Serial Port 3 Format .....	39

**Diagnostic Tests .....** **40**

Table of Diagnostic Tests.....	40
Diagnostic Test 1: Serial Com Port 1 - Display Input Data	
Diagnostic Test 4: Serial Com Port 2 - Display Input Data	
Diagnostic Test 14: Serial Com Port 3 - Display Input Data .....	40
Diagnostic Test 2: Serial Com Port 1 - Display Errors	
Diagnostic Test 5: Serial Com Port 2 - Display Errors	
Diagnostic Test 15: Serial Com Port 3 - Display Errors .....	41
Diagnostic Test 3: Serial Com Port 1 - Transmit Data	
Diagnostic Test 6: Serial Com Port 2 - Transmit Data	
Diagnostic Test 16: Serial Com Port 3 - Transmit Data .....	41
Diagnostic Test 10: Lamp Test .....	41
Diagnostic Test 11: Print the EAROM Configuration Table .....	41
Diagnostic Tests 12 & 13: Loop Back Tests .....	41

**Troubleshooting.....** **42**

Problems And Probable Causes.....	42
Error Messages .....	44

**Hardware and Wiring .....** **45**

Serial Port 1 Connector - TB 3 (Com1) Desktop & Stainless .....	45
Serial Port 2 Connector - TB 5 (Com2) Desktop Model 10809 Motherboard .....	45
Stainless Steel Wall Mount or Panel mount	
Serial Port 2 Connector - TB 5.....	46
Desktop Serial Port COM 3 RS232 DB9 Scale Interface Port.....	46
Stainless Steel Models Serial Port COM 3 TB7 Scale Interface.....	46
Stainless Steel Wall Mount or Panel Mount Serial Port 3 RS485/TTL Connector - TB 6.....	47
Digital/ Parallel Port Connector – TB2 & TB4 .....	47
P.C. Board Diagram - Connectors, Jumpers, and Switches .....	48
Sample Cable Drawings.....	49
IDS150A/152/160/320 .....	49
DT210/IDS550/IDS710/PC (Continuous Output Port).....	49
Parallel (Centronix) Printer .....	51
Remote Switch Inputs.....	51

**DT200 Specifications.....** **53**

**ASCII CHART.....** **54**

# Introduction

---

Congratulations on your purchase and welcome to the DT200 User's Manual. This manual describes the installation and operation of the DT200 data terminal. The DT200 is designed for use in industrial environments to perform the following functions:

- Data entry and data collection.
- Computation.
- Reporting.
- Control.
- Additional Functions - trip level event monitor, programmable "Scale Basic" functions, TTL level 'setpoint' inputs and outputs, and remote control via TTL inputs or RS232 serial input.

The DT200 has three bi-directional serial communication ports that are used for weight indicator input, printer output, bar code input, computer communications, and remote control. The serial ports support RS232, RS422, RS485, and 20ma Current Loop communication.

The DT200 has one parallel TTL I/O port for output to a printer or for setpoint input/output. The TTL inputs can be used for remote control (ZERO, TARE, GROSS/NET, PRINT).

## What's In Each Section

---

This manual is organized and divided into separate sections, which describe the installation, setup, operation, and testing of the DT200. Some Sections, such as **Installation and Setup** are intended for trained scale technicians familiar with the installation of computer equipment. Other sections present information applicable to a user, installer, or system integrator.

The importance of certain information in various sections depends on what features of the DT200 are to be utilized. It is recommended that each installer and user review all sections of the manual and determine what information is useful to his personal needs.

**Installation and Setup** allow a user to quickly get the DT200 working for simple use and testing.

**Set Operation Parameters** and **Parameter Functions** concentrate upon setup parameters and interfacing to peripheral devices such as printers, computer, PLCs, remote displays/scoreboards, etc.

**Diagnostic Tests** and **Troubleshooting** supply fast and simple diagnostic and troubleshooting instructions.

**Hardware and Wiring Diagrams** provides all external-wiring instructions.

### **Scale Basic / Event Monitor Programming**

The DT200 offers "Scale Basic" programming capabilities, which allow you to customize the operation of the DT200 to your application. Scale Basic is designed to be similar to the common BASIC language used in computer programming.

Event Monitors work with Scale Basic functions to provide event driven programming capabilities, such as activating setpoint relays. Events trigger actions; Event Monitors activate Scale Basic functions.

A Scale Basic & Event Monitor Programming Manual may be obtained through your IDS Dealer

## **WARRANTY INFORMATION**

---

### **INDUSTRIAL DATA SYSTEMS, INC. LIMITED WARRANTY.**

Industrial Data Systems, Inc., warrants that the products furnished are free from defects in material and workmanship and perform to applicable, published Industrial Data Systems, Inc., specifications for one (1) year from the date of shipment.

THIS WARRANTY IS IN LIEU OF ANY OTHER WARRANTY EXPRESSED OR IMPLIED. IN NO EVENT SHALL INDUSTRIAL DATA SYSTEMS, INC. BE LIABLE FOR LOSS OF PROFITS, OR INDIRECT, SPECIAL OR CONSEQUENTIAL DAMAGES, OR FOR OTHER SIMILAR DAMAGES ARISING OUT OF ANY BREACH OF THIS WARRANTY PROVISION.

The liability of Industrial Data Systems, Inc. shall be limited to repairing or replacing, WITHOUT CHARGE, any defective products, which are F.O.B Industrial Data Systems, Inc. Plant. Equipment or parts, which have been subject to abuse, misuse, accident, alteration, neglect, unauthorized repair or installation, are not covered by warranty. Industrial Data Systems, Inc. shall have the right of final determination as to the existence and cause of defect. As to items repaired or replaced, the warranty shall continue in effect for the remainder of the warranty period, or for ninety (90) days following date of shipment by Industrial Data Systems, Inc. of the repaired or replaced product, whichever period is longer. No liability is assumed for expendable items such as lamps and fuses. No warranty is made with respect to customer equipment or products produced, to Buyer's specifications except as specifically stated in writing by Industrial Data Systems, Inc. and contained in the contract. In no case is product to be returned without first obtaining permission and a Customer Return Authorization Number (RMA) from Industrial Data Systems, Inc. Product being returned during or after the original warranty period should be carefully packed and sent prepaid and insured along with an explanation of the problem. Customer shall be responsible for all damages resulting from improper packaging or handling, and for loss in transit. If it is found that Industrial Data Systems, Inc. product has been returned without cause and is still serviceable, customer will be notified and Product returned at customer's expense. Repairs or replacements made by Industrial Data Systems, Inc. on Products under warranty will be returned, shipped at NO CHARGE by method of shipment Industrial Data Systems, Inc. deems most advantageous.

EXCEPT AS SPECIFICALLY PROVIDED HEREIN, THERE ARE NO OTHER WARRANTIES EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

**RETURN POLICY** Any piece of equipment purchased by the original purchaser can only be returned for credit or exchange during the first 45 days after shipment. This policy excludes any returns for warranty consideration. Items returned for other than warranty is subject to a restock fee equal to 10% of the list price of the hardware. This fee is assessed for packaging, handling, testing, inspection, and the resultant paperwork that is required to receive and return the hardware to stock for resale.

All such items should be returned in its original shipping container. Any damage not reported when the purchaser originally received the hardware or software is also subject to reasonable repair fees to bring it back to new condition. The purchaser will be advised of these fees in writing at the time they are assessed.

All items returned should be returned with a Return Material Authorization number ( RMA ) issued by an IDS employee. The RMA number should be clearly marked on the outside of the box.


# General Description

---

This section gives you a general description on the operation of the DT200's keyboard and display. The keyboard is used to initiate functions, for data entry, maintenance, setup, and testing. The numeric display is used for weight and error display and for data entry. The LED status lights indicate the status of the weigh scale. Additional information about the keyboard and display is provided in section: **Using the DT200.**

## DT200 Display and Keyboard Diagram

---



## The DT200 Display

---

The DT200 DISPLAY consists of an 8 character NUMERIC display and 6 status indicators. The NUMERIC display is normally used to display the weight on the scale. The status indicators display the scale status. When lighted they indicate the following conditions:

- GROSS-        The number displayed is the gross weight on the scale.
- NET -         The number displayed is the net weight on the scale.



MOTION-	The weight on the scale is changing (not stable).
ZERO-	The scale is at "Center of Zero".
lb-	The weight displayed is in increments of pounds.
kg-	The weight displayed is in increments of kilograms.

## **The DT200 Keyboard**

---

The keyboard is used to initiate functions and for data input and setup of the DT200. It is divided into 3 sections: Numeric Keypad, Function Keys, and Control keys as shown on the previous page.

### **Numeric Keypad**

The numeric keypad is used for numeric data entry. Alphanumeric entry is performed using a three-digit code for every alphanumeric character. Some system parameters may require alphanumeric entry. Instructions for alphanumeric entry are provided where needed.

### **Function Keys**

The function keys ZERO, TARE, GROSS/NET, UNITS and PRINT are used to initiate weighing specific functions. The function keys are programmable using Scale Basic functions.

### **Control Keys**

The control keys ENTER, and CLEAR are used to control the data entry operations for ID's, setpoints and setup.

# Installation and Setup

---

This section provides information about unpacking, installing, and setup of the DT200. It also directs the installer to the appropriate sections of the manual for hardware and setup installation.

## Unpacking the DT200

---

Installation begins with unpacking the DT200. Observe any instructions or cautions, which appear in the shipping container. Check the items in the shipping container against the following item check list or the packing list. IDS, Inc. will not accept responsibility for shortages against the packing list unless notified within 30 days. All equipment and accessories are inspected and tested by IDS before shipment. Inspect the equipment carefully. If shipping damage is evident, notify the carrier immediately. Take photographs if necessary. You are responsible for final claim and negotiations with the carrier. Save the packing and shipping container in case you need to store, return, or transport the DT200 for any reason.

### Item check list

- DT200 – Data Terminal
- Power supply
- Power cord
- This User's Manual

NOTE: The container may include additional items that have been purchased separately.

## Installation Guide

---

### Connect DT200 to weight indicator (optional)

See the HARDWARE INSTALLATION AND WIRING section for pin assignments and a sample cable drawing.

### Connect DT200 to the printer (optional)

The DT200 can be connected to a printer using Com Port 1 for RS232 or Current Loop interfaces or by using the TTL I/O Port for Centronix compatible interfaces. See **Hardware and Wiring Diagrams** for pin assignments and sample cable drawings. See **Set Operation Parameters**, and **Parameter Functions** for other communication setup parameters.

### Connect DT200 to host device (optional)

The Serial Communications Port 2 provides a continuous output of data. This is used for connection to a host device such as a computer or to a remote display (scoreboard). Continuous output transmission can be enabled or disabled and the output format can be customized to interface with the host device. See **Hardware and Wiring Diagrams** for

pin assignments and sample cable drawings. See **Set Operation Parameters**, and **Parameter Functions** for other communication setup parameters.

## Apply AC Power to the DT200

Remove the bottom cover of the DT200 to provide access to the DT200 circuit board.

Connect the output of the power supply to terminal block TB1 (Power AC/DC) on the DT200 circuit board. Re-assemble the DT200. Plug the power cord into the power supply. Plug the power supply cord to main power.

Note: The socket outlet should be installed near the equipment and shall be easily accessible.

On power-up, the DT200 performs the following tests:

1. Keyboard Scan - the keyboard is scanned to verify that no keys are engaged.
2. Memory Test - the DT200 displays "rTEST" while it performs a memory test on internal memory. If a problem is encountered during the test, an error message is displayed.
3. Lamp Test - all segments on the numeric display and all LED's are turned on for 5 seconds.

To exit the above power on test functions, press the CLEAR key during any test. This is possible only if the DT200 has not been locked.

The DT200 is now ready for **initialization**, calibration, and configuration. Continue with Setup Guide.

## Setup Guide

---

Setup the DT200 in the following order:

### Initialize to Factory Defaults

The DT200 is initialized at the factory. It must be re-initialized if the program memory (EPROM) or the parameter memory (EAROM) is replaced. The Initialize function clears the memory and sets the configuration parameters to their default values. Use parameter function 70 described in **Parameter Functions** to initialize the DT200.

**NOTE: Setup must be performed after the DT200 is initialized.**


# Using the DT200

---

The DT200 has 7 function keys located at the bottom of the keyboard, a numeric keypad, and 2 control keys (ENTER, and CLEAR). This section of the DT200 manual describes what the keys are used for and how to use them.

## Keyboard Layout

---



## Operation of Function Keys

---

The function keys are located on the bottom of the DT200's front panel.

### Tare

#### AUTO TARE:

Press the TARE key. The DT200 reads the weight on the scale and stores it in the tare register. The DT200 switches to NET mode and displays the net weight.

#### KEYBOARD TARE:

Use the numeric keys to enter a tare weight. Press the TARE key. The DT200 stores the entered weight in the tare register and switches to NET display mode.

**CLEAR TARE:**

Press the numeric Zero key. Press the TARE key. The tare weight is cleared to zero and the DT200 switches to the GROSS mode.

**Gross/Net**

Press the Gross/Net key to alternate between Gross and Net display modes.

**Print**

Press the PRINT key to print weight data. Page format 1 is printed if the DT200 is in Gross display mode; page format 2 is printed in the Net display mode. See section **Parameter Functions** for setup of print formats.

**F1 and F2**

The F1 and F2 keys can be configured (parameters 57 and 58) to execute any scale basic function.

**When the indicator is in data entry mode, the F1 key can be used for entering a minus sign; the F2 key can be used to enter a decimal point.**

**Memory Register Entry**

Use the numeric keypad to enter the memory register number (1 to 16). Press the ENTER key. The DT200 displays "reg xx" for 1 second and then displays the current memory register value. Press the CLEAR key if no change is to be made, or enter a new value and then press the ENTER key. Memory registers are used by the Event Monitor to calculate setpoint values. NOTE: memory registers are set to zero at power up unless the battery back up is enabled (parameter 41).

**Execute a Scale Basic Function**

The DT200 provides up to 16 user programmable functions. User programs 1 thru 16 can be executed by entering 21 to 36 respectively. See the "Scale Basic / Event Monitor" manual for more information.

**Display Time/Date**

Enter 19 to display the time, press Enter key to display the date, press Enter again to return to Gross/Net display.

# Built In Application Programs

---

The following built in programs are available:

1. Fill to Setpoint.
2. Checkweigh: Under/Between/Over.
3. Weigh-in / Weigh-out.
4. Axle Weigh – Short Scale.
5. Axle Weigh – Long Scale.
6. ID Tare and Total.

Use parameter function 73, “Initialize Function Memory”, to activate a built in program. The initialize function erases function memory and setpoint monitor memory, and initializes all parameters that have a password level of 1 or 2. Use parameter function 73 before configuring parameters with password level of 1 or 2.

---

## #1 Fill to Setpoint

---

Press F1 key to enter a setpoint. Place an empty container on the scale. Press F2 key to begin filling. TTL output 1 turns on until the weight on the scale is equal or greater than the setpoint.

### Installation

Connect TTL output 1 to relay or lamp actuator.

TB4 - Pin 1    TTL output 1

TB4 - Pin 16    Ground (GND)

### Setup Parameters:

(See chapter 5: Set Operation Parameters for setup details)

Parameter 43 Minimum scale weight to begin filling. Verifies that a container is on the scale. Set to 0 if there is no minimum.

Parameter 44 Minimum fill amount. Set to some small value to insure that a fill amount has been entered.

Parameter 45 Maximum fill amount. Maximum fill weight that will ever be used.

Parameter 46 Scale empty weight. Maximum weight to begin fill. Verifies that an empty container is on the scale.

## Operators Functions

### Enter setpoint

Press **F1** key to enter the setpoint. Enter the setpoint weight, then press the ENTER key.

### Start fill operation

Place the container on the scale (if required). Press **F2** key to begin fill operation.

### Stop fill operations

Press the **Clear** key to stop fill operation.

### Print Results

Press the Print key to print the Gross, Tare, and Net results of the fill operation.

### Error Codes

Error 30 = scale not empty

Error 31 = minimum weight error: container is not on scale

Error 32 = tare weight error: tare function failed, scale not stable (motion)

Error 33 = setpoint less than minimum setpoint amount

Error 34 = setpoint more than maximum setpoint amount

## # 2 Checkweigh: Under/Between/Over

---

The indicator monitors the scale for activity. When the scale goes above the 'empty' weight, the indicator waits for stable weight, and then outputs an indication of Under, Between (OK), or over. The cycle resets when the scale goes below the empty weight.

### Installation

Connect TTL outputs to relay or lamp actuators.

Under weight indication	TTL 1	TB4 - Pin 1
Between weight indication	TTL 2	TB4 - Pin 2
Over weight indication	TTL 3	TB4 - Pin 3
Ground	GND	TB4 - Pin 16

Configure 'empty' scale weight. (Parameter 43)

### Operators Functions

#### Enter setpoint weights

Press the F1 key. The display prompts "SP 1. Use the numeric keyboard to enter setpoint 1, then press the ENTER key. The display prompts "SP 2". Use the numeric keyboard to enter setpoint 2, then press the ENTER key. NOTE: use the F2 key to enter a decimal point if needed.

#### Recalculate

Press the F2 key to re-check the weight on the scale.



## # 3 Weigh-in / Weigh-out

---

This program uses the ID memory for weigh-in / weigh-out transactions. An ID record is created using the Weigh-in function. The Weigh-out function recalls the ID, calculates Gross/Tare/Net of the transaction, prints the transaction, and adds the net weight to the ID's totals register. The ID data is saved for further weigh-in/weigh-out transactions, or weigh-out only transactions. A sequential transaction number is maintained for printing purposes.

### Weigh-In

Press the **F1** key. The display prompts "id". Enter up to 8 digits for the weigh-in ID and then press the ENTER key. The scale weight is stored in the ID's tare register and print page 3 is sent to the printer. For keyboard tare, enter the ID number and press the TARE key (not the ENTER key). Enter the tare weight and press the ENTER key. If the ID has been weighed in but not weighed-out then "Err 20" is displayed. Press the CLEAR key to exit without changing the ID data, press the ENTER key to enter the new ID data.

### Weigh-Out

Press the **F2** key. The display prompts "id". Enter up to 8 digits for the weigh-out ID and then press the ENTER key. The indicator recalls the ID from memory, calculates the gross, tare and net weights, totals the net weight and sends the weigh-out data (page 2) to the printer. If an ID is entered that is not found in memory the displays "Err 21". Press the CLEAR key to exit the weigh-out function.

The print formats label "(IN) GROSS" for weigh-in gross transactions, "(IN) TARE" for weigh-in tare transactions, and "MEM TARE" to designate Memory tare for ID's recalled 2 or more times.

### Print ID's, Display ID's, Clear Totals, Erase ID's

Entering ID 0 accesses the ID maintenance functions. Press the F1 (or F2) key, press the numeric 0 key, and then press the ENTER key. The display prompts "rePort". Press the UNITS (↓) key or the PRINT (↑) key to scroll through the ID file maintenance menu.

**REPORT:** Press the ENTER key when the display prompts "rePort". The display then prompts "id". Enter an ID number to be printed or enter the numeric 0 to print all ID's.

**DISPLAY ID's:** Press the ENTER key when the display prompts "diSPLA". The display then prompts "id". Enter an ID number to display the data in its registers, or enter 0 to scan ID memory.

**CLEAR TOTALS:** Press the ENTER key when "CLEAR" is displayed. The display prompts "id". Enter an ID number to clear or enter the numeric 0 to clear all ID totals.

**ERASE ID'S:** Press the ENTER key when the display prompts "ErASE". The display then prompts "id". Enter an ID to be erased or enter the numeric 0 to erase all ID's.

**REBUILD ID MEMORY:** Press the ENTER key when the display prompts, “rebuiLd”. The display then prompts “id”. Enter the numeric 0 then press ENTER to rebuild ID memory.

**COUNT UNUSED ID’S:** Press the ENTER key when the display prompts “Count”. The display prompts “FrExxx” where xxx is the number of unused ID records in memory.

## Set Beginning Sequence Number

Use the numeric keypad to enter number 9. The display prompts "reg 9" for 1 second and then displays the current value. Press the CLEAR key if no change is to be made, or enter a new value and then press the ENTER key. The next sequence number printed will be the entered value +1.

## Options

- **Print key:** Set parameter 52 = 4 (execute user function 4) to enable the print key to print the weight on the scale. The print data is sent to Serial Communications Port 1. If units other than lb are used, change print label 85 to the correct units. (This option is not available for printers that use the parallel output port).
- **Unit’s key:** Set parameter 53 = 127 (execute Units function) if weighing is dual units is required.

## Notes

- The ID file maintenance functions are password level 1 protected. If a password has been configured (function 64) the operator will be prompted for the password before the file maintenance menu is displayed.
- ID memory is cleared to zero at power up unless CFG parameter 41 (battery back up enable) is set to 1.

## # 4 Axle Weigh – Short Scale

---

Automatically weigh multiple axles (or containers), print each axle weight, and print axle total.

### Installation

Connect the Red light / Green light relays.

Green light = TTL out 1      TB4 pin 1

Red light =    TTL out 2      TB4 pin 2

### Setup Parameters

Configure the following parameters:

- |                 |  |
|-----------------|--|
| Parameter 43    | Trip level weight. Determines when an axle is on the scale.                                      |
| Parameter 74, 1 | Red light turn delay timer. This provides a delay time before the Red light output is turned on. |
| Parameter 74, 2 | Green light turn delay timer. The amount of delay time before the Green light is turned on.      |
| Parameter 74, 3 | Finish timer. Amount of time to wait before automatically activating the finish function.        |

### Operators Functions

The unit is capable of operating unattended, with no operator intervention. The indicator determines when an axle is on the scale by the increase (or decrease) of weight on the scale.

A finish timer (parameter 74-3) determines when to complete a weigh cycle (print total and wait for empty scale).

Press the **F1** key to manually finish a weigh cycle before finish timer has timed out.

Press the **F2** key to abort weigh cycle.

## # 5 Axle Weigh – Long Scale, Unattended

---

Automatically weigh multiple axles (or containers), print each axle weight, and print axle total.

### Installation

Connect the Red light / Green light relays.

Green light = TTL out 1      TB4 pin 1

Red light = TTL out 2      TB4 pin 2

### Setup Parameters

Configure the following parameters:

- |                 |  |
|-----------------|--|
| Parameter 43    | Trip level weight. Determines when an axle is on the scale.                                      |
| Parameter 74, 1 | Red light turn delay timer. This provides a delay time before the Red light output is turned on. |
| Parameter 74, 2 | Green light turn delay timer. The amount of delay time before the Green light is turned on.      |
| Parameter 74, 3 | Finish timers. Amount of time to wait before automatically activating the finish function.       |

### Operators Functions

The unit is capable of operating unattended, with no operator intervention. The indicator determines when an axle is on the scale by the increase of weight on the scale.

A finish timer (parameter 74-3) determines when to complete a weigh cycle (print total and wait for empty scale).

Press the **F1** key to manually finish a weigh cycle before finish timer has timed out.

Press the **F2** key to abort weigh cycle.

## # 6 ID, Tare, and Total

---

This program uses the ID memory to store tare weights and totals.

### Enter ID Tare Data

Press the **F1** key. The display prompts "id". Enter up to 8 digits for ID and then press the ENTER key. The display prompts "tArE". Enter the tare weight.

### Recall ID and Tare

Press the **F2** key. The display prompts "id". Enter up to 8 digits for the weigh-out ID and then press the ENTER key. The indicator recalls the ID from memory and copies the ID tare to the tare register.

### Print and Total ID

Recall an ID and then press the Print key. The ID number, Gross, Tare, and Net are printed. The Net weight is added to the ID's totals register.

### Print ID's, Display ID's, Clear Totals, Erase ID's

Entering ID 0 accesses the ID maintenance functions. Press the F1 (or F2) key, press the numeric 0 key, and then press the ENTER key. The display prompts "rePort". Press the UNITS (↓) key or the PRINT (↑) key to scroll through the ID file maintenance menu.

**REPORT:** Press the ENTER key when the display prompts "rePort". The display then prompts "id". Enter an ID number to be printed or enter the numeric 0 to print all ID's.

**DISPLAY ID'S:** Press the ENTER key when the display prompts "diSPLA". The display then prompts "id". Enter an ID number to display the data in its registers, or enter 0 to scan ID memory.

**CLEAR TOTALS:** Press the ENTER key when "CLEAr" is displayed. The display prompts "id". Enter an ID number to clear or enter the numeric 0 to clear all ID totals.

**ERASE ID'S:** Press the ENTER key when the display prompts "ErASE". The display then prompts "id". Enter an ID to be erased or enter the numeric 0 to erase all ID's.

**REBUILD ID MEMORY:** Press the ENTER key when the display prompts, "rebuiLd". The display then prompts "id". Enter the numeric 0 then press ENTER to rebuild ID memory.

**COUNT UNUSED ID'S:** Press the ENTER key when the display prompts "Count". The display prompts "FrExxx" where xxx is the number of unused ID records in memory.

### Set Beginning Sequence Number

Use the numeric keypad to enter number 1. The display prompts "reg 1" for 1 second and then displays the current value. Press the CLEAR key if no change is to be made, or enter a new value and then press the ENTER key. The next sequence number printed will be the entered value +1.

**Notes**

- The ID file maintenance functions are password level 1 protected. If a password has been configured (function 64) the operator will be prompted for the password before the file maintenance menu is displayed.
- ID memory is cleared to zero at power up unless parameter 41 (battery back up enable) is set to 1.

# Set Operation Parameters

---

This section describes the operation parameters of the DT200 and how their settings affect the operation of the weight indicator.

## Access Operation Parameters and Parameter Functions

---

The parameters are accessed by holding the CLEAR key down and then pressing the ENTER key. The numeric display will prompt “CFG xx” where xx is the currently selected parameter. Enter the parameter number to be modified and then press the ENTER key. NOTE: the UNITS key (↓) and the PRINT key (↑) can be used to scroll the CFG parameter number. Press the UNITS key to increment the CFG number, press the PRINT key to decrement the CFG number.

To exit configuration and store changes, press the CLEAR key when “CFG xx” is being displayed.

To exit configuration and NOT store changes, enter 999 when “CFG xx” is being displayed. The display prompts “Abort”. Press the ENTER key to abort (exit without saving changes) or press the CLEAR key if you do not want to abort.

## Operation Parameters Reference Tables

---

The reference tables provide an overview of the operation parameters. The sections following the reference tables describe the setup parameters in detail and the procedures for modifying them. Use the ‘Field Settings’ column of the reference tables to document any changes to the setup parameters.

Reference Table column headings descriptions:

- **No.:** Use this number to access the parameter to be modified. For example to modify the Digital Filter enter CFG 2.
- **Parameter Name:** The name of the parameter.
- **Default:** The value set at the factory. The Parameter Function “Initialize Operation Parameters to Factory Defaults” sets the parameter to this value.
- **Max Value:** The maximum value for numeric parameters, the maximum number of characters for alphanumeric parameters.
- **Pass:** The DT200 has 4 password levels. Level 1 requires entering password-1 before accessing the parameter. Level 2 requires password-2. Level 3 requires password-2 and the Lock Switch to be in the unlocked position. Level 4 inhibits Scale Basic functions from being uploaded to a PC.
- **Field Setting:** Record any changes to the parameters in the Field Setting column.

**Scale Parameters**

No	Parameter Name	Default	Max Value	Pas	Field Setting
1		3	4	3	
2		9	18	3	
3		1	200	3	
4		6	250	3	
5		6	250	3	
6		0 (no)	1	3	
7		0	250	3	
8		12	250	3	
9		100	100	3	
10	Primary units type	1 (lb)	6(oz)	3	
11	Decimal point position	0	4	3	
12	Count-by	1	100	3	
13		2 (kg)	6(oz)	3	
14		1	4	3	
15		5	100	3	
16		45,360		3	
17		10,000	120,000	3	
18		10,200	120,200	3	
19				3	
20		1	1	3	
21				3	
22				3	

**I/O Port Parameters**

No	Parameter Name	Default	Max Value	Pas	Field Setting
23	Serial port 1 mode	4(8N1)	6	2	
24	Serial port 1 baud rate	1(9600)	6	2	
25	Serial port 2 mode	4(8N1)	6	2	
26	Serial port 2 baud rate	1(9600)	6	2	
27	TX2 control / Station Id	255	255	1	
28	TX2 Data Format	1 (AND)	4	2	
29	Printer port select	2 (Com1)	2	2	
30	Autoprint LF after CR	1 (yes)	1	2	
31	End Of Print character	12 (ff)	255	2	
32	Print label 32		16 char	2	
33	Print label 33		16 char	2	
34	Print label 34		16 char	2	
84	Print label 84		30 char	2	
85	Print label 85		30 char	2	
86	Print label 86		30 char	2	
87	Print label 87		30 char	2	



88	Print label 88		30 char	2	
89	Print label 89		30 char	2	
90	Print label 90		30 char	2	
35	Print code 1		3 codes	2	
36	Print code 2		3 codes	2	
37	Print code 3		3 codes	2	
38	Print code 4		3 codes	2	
39	TTL remote control	1 (yes)	1	2	

### Display Intensity, Battery, Watchdog Timer

No	Parameter Name	Default	Max Value	Pas	Field Setting
40		10	15	2	
41	Battery backup enable	0 (no)	1	2	
42	Enable watch dog timer	1 (yes)	1	1	

### Fixed Setpoints

No	Parameter Name	Default	Max Value	Pas	Field Setting
43	Fixed setpoint 43	0		1	
44	Fixed setpoint 44	0		1	
45	Fixed setpoint 45	0		1	
46	Fixed setpoint 46	0		1	
47	Fixed setpoint 47	0		1	
48	Fixed setpoint 48	0		1	
49	Fixed setpoint 49	0		1	
50	Fixed setpoint 50	0		1	

### Keyboard Events

No	Parameter Name	Default	Max Value	Pas	Field Setting
51	Power on start	0	255	2	
52	PRINT key	136	255	2	
53	UNITS key	127	255	2	
54	Gross/Net key	128	255	2	
55	TARE key	129	255	2	
56	ZERO key	130	255	2	
57	F1 key	138	255	2	
58	F2 key	139	255	2	

## Parameter Functions

Fn. No	Function Name	Password Level
59	Display Calibration Audit Number	0
60		3
61		3
62		3
63		3
64	Configure Passwords	2
65	Configure Print Formats	2
66	Set Time and Date	2
67	Display Operation Parameters	0
68	Print Operation Parameters	0
69	Diagnostic Tests	0
70	Initialize Operation Parameters to factory defaults.	3
71	Configure Event Monitor	2
72	Function Editor	2&3
73	Initialize Function Memory	2
74	Set Debug mode for Event monitors and Scale basic fns.	2
75	Enable Peak Detect (optional)	2
76	Set debug mode for event monitors and scale basic fns.	2
78	Erase Id Memory	1
79		3
80		3
81	Analog output offset (default = 0)	1
82	Analog output span (default = 10,000)	1
83	Analog output register (default = 0 [disabled])	1
84-90	Print labels 4 to 10	
91	Serial Port 3 mode	4
92	Serial Port 3 baud rate	1
93	Serial Port 3 input format (default = 1 [Condec])	1

## Scale Parameters

The scale parameters configure DT200 for the weigh platform or load cell that it is connected to. The preceding table titled “SCALE PARAMETERS” lists the scale parameters and their factory settings. Use the “Field Setting” column to record any changes made to the factory default values.

The numbers in parenthesis are the default factory settings.

**Parameter 10. Primary Units Type (1 [lb])**

The scale is calibrated in the primary units. The UNITS key is used to toggle the weight display between primary units and alternate units. Enter the number that corresponds with the primary units:

- 0 = UNDEFINED, no units printed
- 1 = lb
- 2 = kg
- 3 = ton
- 4 = ten
- 5 = gram
- 6 = oz
- 7 = use print label 32 for units
- 8 = use print code 1 for units

NOTE: when parameter 10 is changed, parameters 13 and 16 must be programmed.

**Parameter 11. Decimal Point Position (0 [no decimal point])**

Enter the decimal point position for the primary units display. For example, if the scale is calibrated x 0.05 the decimal position = 2.

**Parameter 12. Count-by (1)**

Enter the primary units count-by. For example, if the scale is configured for:

- x 0.05            count-by = 5
- x 0.2             count-by = 2
- x 1                count-by = 1
- x 5                count-by = 5
- x 50              count-by = 50

Note: the entry for 0.05 and 5 is the same. The decimal point position (parameter 11) differentiates between the count-by 0.05 and count-by 5.

**Parameter 13. Alternate Units Type (2 [kg])**

Alternate units are the alternate display and print unit of measure that can be used in addition to the primary units. The UNITS switch on the DT200's keyboard toggles the weight display between primary units and secondary units.

- 0 = UNDEFINED, no units printed
- 1 = lb
- 2 = kg
- 3 = ton
- 4 = tne
- 5 = gram
- 6 = oz
- 7 = use print label 32 for units
- 8 = use print code 1 for units

**Parameter 14. Alternate Decimal Point (1)**

Enter the decimal point position for the alternate units display.

**Parameter 15. Alternate Count-by (5)**

Enter the alternate units count-by.

**Serial I/O Ports**

The DT200 is equipped with three bi-directional serial communication ports that can communicate to a weight indicator, an optional printer, a computer, bar code reader, a score board or other serial communication devices. The baud rate and format can be set independently for each port. Serial port 1 is normally used to output weight data and ID reports to a printer. Serial port 2 is normally used for continuous output of weight data. Continuous transmission can be enabled or disabled and the output format can be customized using Parameters 27 and 28. Serial port 3 is used to receive weight data from a weight indicator.

**NOTE: See parameters 91, 92, and 93 for Serial Port 3 settings.**

Communication between serial devices requires that both devices have the same baud rate (transmission speed), data bit length, and parity. The mode parameter selects the data bit length and parity the baud parameter selects the baud rate.

**Parameter 23 Serial Com. Port 1 Mode (4 [8 data bits, no parity])**

Enter the mode number from the table below to select the mode parameter in the mode description column.

Mode Number	Mode Description
1	7 data bits, no parity
2	7 data bits, even parity
3	7 data bits, odd parity
4	8 data bits, no parity
5	8 data bits, even parity
6	8 data bits, odd parity

**Parameter 24 Serial Com. Port 1 Baud Rate (1 [9600 baud])**

Enter a baud number from the table below to select a baud rate from the description column. (\*HS baud rates for the 100 samples per sec version only).

Baud Number	Baud Description
1	9600 Baud
2	4800 Baud
3	2400 Baud
4	1200 Baud
5	600 Baud
6	300 Baud (* HS 19.2K)
7	150 Baud (*HS 38.4K)

**Parameter 25 Serial Com. Port 2 Mode (4 [8 data bits, no parity])**

Enter the mode number from the table below to select the mode parameter in the mode description column.

Mode Number	Mode Description
1	7 data bits, no parity
2	7 data bits, even parity
3	7 data bits, odd parity
4	8 data bits, no parity
5	8 data bits, even parity
6	8 data bits, odd parity

**Parameter 26 Serial Com. Port 2 Baud Rate (1 [9600 baud])**

Enter a baud number from the table below to select a baud rate from the description column. (\*HS baud rates for the 100 samples per sec version only).

Baud Number	Baud Description
1	9600 Baud
2	4800 Baud
3	2400 Baud
4	1200 Baud
5	600 Baud
6	300 Baud (* HS 19.2K)
7	150 Baud (*HS 38.4K)

**Parameter 27 TX2 Control / Station ID (255 [single station])**

Serial Port 2 can be used for continuous transmission of scale data or as a network buss or for single station remote control.

- Enter a 0 to enable continuous transmission of TX 2 data. The data sent is configured in parameter 28 (TX2 Format).
- Enter a station ID (1 to 254) for multi-drop network configuration
- Enter 255 for single station remote control

**Parameter 28 TX2 Format (2 Condec format)**

Serial Port 2 can be used for continuous transmission of scale data. The TX2 Format parameter determines what is sent. There are 5 selections:

1 - AND: <status>, <mode>, <polarity><weight><units><terminate>

Status: OL (overload), ST (stable), US (unstable, in motion)

Mode: GS (gross mode), NT (net mode)

Polarity: + (positive weight), - (negative weight)

Weight: 7 characters data, NOT zero blanked, with decimal point

Units: lb, kg, t (ton), tn (tonne), g<sp> (gram), oz

Terminate: lf, cr (line feed, carriage return)

- 2 - CONDEC: <st><polarity><weight><units><mode>>status><terminate>  
 Polarity: space (positive weight), - (negative weight)  
 Weight: 7 characters, zero blanked, with decimal point  
 Units: L (lb), K (kg), T (ton), G (gram), O (oz)  
 Mode: G (gross mode), N (net mode)  
 Status: <space> (valid weight), M (motion), O (over wt), I(invalid)  
 Terminate: lf, cr (line feed, carriage return)
- 3 - WEIGHTRONIX: <mode1><mode2><polarity><weight><space><units><term>  
 Mode1: space (gross mode), 0 (zero if net mode)  
 Mode2: G (gross mode), N (net mode)  
 Polarity: + (positive weight), - (negative weight)  
 Weight: 6 characters, NOT zero blanked, with decimal point  
 Units: lb, kg, oz, g <space>(gram), t<space> (ton), tn (tonne)  
 Terminate: lf, cr (line feed, carriage return)
- 4 - OHAS: <polarity><weight><space><units><2 spaces><mode><status><term>  
 Polarity: space (positive weight), - (negative weight)  
 Weight: 7 digits, zero blanked, with decimal point  
 Units: lb, kg, oz, g <space>(gram), t<space> (ton), tn (tonne)  
 Mode: G (gross mode), N (net mode)  
 Status: <space> (valid weight), M (motion), O (over wt), I(invalid)  
 Terminate: lf, cr (line feed, carriage return)
- 5 - Print label 85: transmits the contents of parameter 85 (print label 85)  
 Data entered into a print label can include register data:  
 [253] [reg no] buffer register data, minimum size (zero blanked no spaces)  
 [254] [reg no] buffer data, 7 character field, zero blanked, right justified.

## Printer Parameters

---

The DT200 provides a universal printer interface for various printers. The printer interface allows you to select and customize the data output for serial or parallel printers. The serial interface option uses Serial Port 1 (TB1) for connection to the printer. The parallel interface uses the TTL I/O Port (TB4) for connection to the printer. Refer to the “HARDWARE INSTALLATION AND WIRING “ section for information on connector pin designations. NOTE: The parallel interface may not be available if the DT200 is configured to use setpoint outputs.

### Parameter 29 Printer Port Select (2 [Serial Port 1])

Enter a number from the following list to select a printer option:

- 1 Parallel Printer interface.

## 2 Serial Printer interface.

### **Parameter 30 Auto Print LF after CR (1 [yes])**

Some printers require a line feed character (LF) to advance the paper and some printers advance the paper with only a carriage return character (CR).

Enter a 1 to automatically add a line feed after a carriage return.

Enter a 0 to NOT add a line feed after a carriage return.

### **Parameter 31 End of Print Character (12 [form feed])**

The end of print character is sent to the printer at the end of a print transmission. If your printer requires a special character to release the paper or to form feed the paper, enter the code here. The ASCII chart in the appendix lists the ASCII codes and their numeric values. Enter a 0 (zero) if no end of print character is required.

### **Parameters 32, 33 34, 84, 85, 86, 87, 88, 89 and 90 Print Labels**

The DT200 provide 7 programmable print labels. They are available for printing company name, address, station ID, or other messages. Labels 32, 33, and 34 are up to 16 characters long; labels 84 - 90 are up to 30 characters long. Use the ASCII chart in the appendix to look up the numeric values of the ASCII codes. Data entered into a print label can include register data:

[253] [reg no] buffer register data, minimum size (zero blanked no spaces)

[254] [reg no] buffer register data, 7 character field, right justified

Or time & date [253][110], time [253][111], date [253][112].

Example: Print "Total [reg 1 data] ton". Select parameter 32 to begin Print Label 1 entry. The display prompts "C0 xxx" where xxx is the current character 0 entry. Enter:

84, 111, 116, 97, 108, 32, 254, 1, 32, 116, 111, 110, 13, 0

T o t a l <reg1> t o n <cr>

Remember to enter a 0 as the last entry of the print label.

### **Parameters 35, 36, 37, and 38: Print Codes**

The DT200 provides 4 programmable print codes. The print codes are used to send special setup parameters to the printer, such as select print size or select print font. Each print code is up to 4 characters long. Consult your printer manual for the print codes that you may want to use. Enter the codes in decimal format (an ASCII carriage return = 13). Select parameter 35 to begin print code 1 entry. The DT200 prompts "C0 XXX" where xxx is the current character 0 print code value. Enter data for character 0. The DT200 prompts "C1 XXX". Continue the code entry. Enter a 0 to end print code entry.

### **Parameter 39 Enable TTL Remote Control (1 [enabled])**

Use parameter 39 to enable remote control using TTL inputs 1 thru 4 (TB4 pins 10-13).

Enter a 1 to use TTL inputs 1-4 to activate scale basic functions 1 - 4. For example, grounding TB4 pin 10 (TTL input 1) activates scale basic function 1.

Enter a 0 to disable TTL remote control.

## **Battery, Watch Dog Timer**

---

### **Parameter 41 Battery Backup (0 [no])**

The battery is used to preserve the time and date, memory registers, and ID memory when power is lost. Set the Battery Backup parameter to ON (1) to prevent the DT200 from clearing memory when power is restored, set parameter 41 to OFF (0) to erase memory when power is restored.

### **Parameter 42 Enable Watch Dog Timer (0 [no])**

The watchdog timer resets the DT200 when the weight display is not updated within the time-out time (0.2 sec). Set the Enable ON (1) to reset after time-out. Set the Enable OFF (0) to turn off the watchdog timer.

## **Parameters 43-50 Fixed Registers**

---

The Fixed Registers are used by the Trip-Level Event Monitor to determine when a trip-level is reached. See the “Scale Basic / Event Monitor” manual for more information. Parameters 43 thru 50 select Fixed Setpoints 1 thru 8. Select the parameter number to be changed and then enter the trip-level weight.

## **Parameters 51-58 Keyboard Event Functions**

---

The keyboard event functions determine what actions take place when a key is pressed. The Power on start function activates a function when power is applied to the indicator.

<b>Number</b>	<b>Parameter Name</b>	<b>Default Value</b>	<b>Password</b>
51	Power on start function	0 (no function executed)	2
52	PRINT key function	136 (Print function)	2
53	UNITS key function	127 (Units toggle function)	2
54	Gross/Net key function	128 (Gross/Net toggle)	2
55	TARE key function	129 (Tare function)	2
56	ZERO key function	0 (no function)	2
57	Function Key 1 (F1)	0 (no function executed)	2
58	Function Key 2 (F2)	0 (no function executed)	2



# Parameter Functions

The parameter functions are used to set parameters that are too complex for a single numeric entry. The following table lists the parameter functions:

## Parameter Functions

<b>Fn. No</b>	<b>Function Name</b>	<b>Password Level</b>
59	Display Calibration Audit Number	0
60		3
61		3
62		3
63		3
64	Configure Passwords	2
65	Configure Print Formats	2
66	Set Time and Date	2
67	Display Operation Parameters	0
68	Print Operation Parameters	0
69	Diagnostic Tests	0
70	Initialize Operation Parameters to factory defaults.	3
71	Configure Event Monitor	2
72	Function Editor	2&3
73	Initialize Function Memory	2
74	Set Debug mode for Event monitors and Scale basic fns.	2
75	Enable Peak Detect (optional)	2
76	Set debug mode for event monitors and scale basic fns.	2
78	Erase Id Memory	1
79		3
80		3
81	Analog output offset (default = 0)	1
82	Analog output span (default = 10,000)	1
83	Analog output register (default = 0 [disabled])	1
84-90	Print labels 4 to 10	
91	Serial Port 3 mode	4
92	Serial Port 3 baud rate	1
93	Serial Port 3 input format (default = 1 [Condec])	1

The Password Level is used to prevent unauthorized access to parameter functions. See Parameter Function 64, “Configure Passwords”, for more information on passwords.

## **Access Parameter Functions**

---

Hold the CLEAR key down and press the ENTER key. The numeric display prompts “CFG xx” where xx is the currently selected parameter. Enter a parameter function number and then press the ENTER key. NOTE: use the UNITS key (↓) and the PRINT key (↑) to scroll the CFG parameter number. Press the UNITS key to increment the CFG number, press the PRINT key to decrement the CFG number.

To exit configuration and store changes, press the CLEAR key when “CFG xx” is being displayed.

To exit configuration and NOT store changes, enter 999 when “CFG xx” is being displayed. The display prompts “Abort”. Press the ENTER key to abort (exit without saving changes) or press the CLEAR key if you do not want to abort.

### **Example: Begin Calibration of the Scale-**

The DT200 is in the display weight mode. Hold the CLEAR key down and press the ENTER key to enter the configure mode. The DT200 prompts “CFG xx” where xx is the last selected parameter. Enter 60 and then press the ENTER key. The DT200 prompts “dEAdld”. Begin the calibration process or press the CLEAR key to exit.

## **Function 59 Display Calibration Audit Number.**

---

Use function 59 to view the audit and configuration numbers, the software ID number, and the status of the internal function lock.

The DT200 provides a calibration audit number and a configuration number. They are used to indicate changes to calibration data and configuration data and can be used in place of mechanical seals by some regulatory agencies. The DT200 audit number increments each time a calibration parameter is changed (deadload or weight conversion factor). The configuration number increments each time a password level 3 parameter is changed. If physical seals are used, then place the internal function lock in the locked position before sealing. Calibration and password level 3 parameters cannot be accessed when the function lock is in the locked position.

1. Hold the CLEAR key down and press the ENTER key to enter the configure mode.
2. Enter CFG 59. The DT200 prompts “A xxxx” where xxxx is the audit number.
3. Press the ENTER key. The DT200 prompts “C xxxx” where xxxx is the current calibration number.
4. Press the ENTER key. The DT200 prompts “bixxxx” where bixxxx is the ID number of the software installed in the DT200.
5. Press the ENTER key. The DT200 prompt “un-LoC” if the function lock is in the unlocked position, or “Loc Ed” if the function is in the locked position.

## Function 64 Configure Passwords

---

Use function 64 to enter password data. The DT200 provides two security passwords that can be activated and entered to protect configuration data. Password 1 is used to protect I/O port configuration, setpoint, and event monitor data. Password 2 is used to protect calibration and scale configuration data. Security level 3 provides extra protection for password level 2 data. Security level 3 requires the entry of password 2 and the Function Lock inside the DT200 to be in the unlocked position. Password 3 will inhibit viewing, changing, and uploading of Scale Basic functions to a PC when password is active but will allow downloading a new Scale Basic program from the PC to the indicator. All passwords will be disabled once the new program has been downloaded into the indicator and should be reactivated.

The Operation Parameter Reference Table lists the configuration parameters and the password/security level required to access them. The DT200 prompts “PASS 1” when a parameter is selected that requires password level 1. If the entered password is incorrect, the DT200 displays “Error”. Press the ENTER key to try again. Press the CLEAR to exit from password entry.

**IMPORTANT NOTE:** Write down the passwords and put them in a safe place. If you loose and forget a password, there is no way to access the protected functions.

1. Hold the CLEAR key down and press the ENTER key to enter the configure mode.
2. Enter CFG 64. The DT200 prompts “P1 xxxx” where xxxx is the current password number. Enter a new password number or press the ENTER key to use the displayed number. Enter a 0 (zero) for the password number to disable the password.
3. The DT200 prompts “P2 xxxx”. Enter password 2 data.
4. The DT200 prompts “P3 xxxx”. Enter password 3 data.

## Function 65 Configure Print Formats

---

Use function 65 to modify print formats to meet your print requirements. The print formats are grouped into PAGES that are used for generating print data onto a form. Each page is organized into rows and columns as follows:

Line No.	Column No.	Item No.

Line No. = Line number on the page to print the item on.

Column No. = Column position where item print begins.

Item No. = Item to print.

Print format design requires you to become familiar with the PAGE LIST and the PRINT ITEM LIST. The PAGE LIST describes how each PAGE is used. The PRINT ITEM LIST describes what ITEMS can be included in each page. Use the print format worksheets to design new print formats. The PRINT FORMAT DESIGN EXAMPLE illustrates how a print format is designed. A list of the default print formats is found in

DEFAULT PRINT FORMATS. The print formats (PAGES) are initialized to factory settings when the Initialize System Parameters function is used. (parameter function 73).

### **Modify or Design a Print Format**

1. Hold the CLEAR key down and press the ENTER key to enter the configure mode. Enter CFG number 65.
2. The DT200 prompts "PAGE". Enter the Page number that you want to modify.
3. The DT200 prompts "Px E1" where x is the page number that you entered and E1 indicates that the current entry being modified is entry 1. Press the ENTER key.
4. The DT200 prompts "L x" where x is the line number on the page that entry 1 is to print on. Enter a new line number or press ENTER to use the displayed number.
5. The DT200 prompts "C x" where x is the column number on the page that entry 1 is to print on. Enter a new column number or press ENTER to use the displayed number.
6. The DT200 prompts "i x" where x is the item number that is to be printed. (See Print Item List for a description of items that can be printed). Enter a new item number or press the ENTER key to use the displayed number.
7. The DT200 prompts "Px E2". Use the procedure above to modify entry 2. Use the UNITS key (↓) to scroll forward in the page table, use the PRINT key (↑) to scroll backwards.
8. Enter a zero (0) for the line number (L 0) after the last entry that is to be printed. Press the CLEAR key to exit from the current page. NOTE: if the 16<sup>th</sup> entry is used, then a zero entry for the line number is not necessary.

**Page List**

FORMAT	DESCRIPTION
PAGE 1	Prints when the DT200 is in the GROSS weight mode.
PAGE 2	Prints when the DT200 is in the NET weight mode.
PAGE 3	Used by Scale Basic functions when needed.
PAGE 4	Used by Scale Basic functions when needed.

**Print Item List**

Item #	Description
2-4	Print Label 1, 2, and 3 (see chap. 5: Set I/O Port, parameters 32-34)
84-90	Print Labels 4 thru 10. (Parameters 84-90)
5	Gross Weight (primary units)
6	Tare Weight (primary units)
7	Net Weight (primary units)
8	Gross Weight labeled "WEIGHT" (primary units)
9	Scale Status (used by continuous transmit)
10	Time and Date (battery/time & date option required)
11	Time (battery/time & date option required)
12	Date (battery/time & date option required)
15	Gross Weight (alternate units)
16	Tare Weight (alternate units)
17	Net Weight (alternate units)
18	The Displayed weight (in the displayed units and mode)
21	Print Code 1 (see section: <b>Set I/O Port Parameters</b> , params 35-38)
22	Print Code 2
23	Print Code 3
24	Print Code 4
25	Gross Weight (display units)
26	Tare Weight (display units)
27	Net Weight (display units)
32	Space holder, does nothing.
33	Form Feed (ASCII 12)
34	Carriage Return (ASCII 13)
35	Line Feed (ASCII 10)
40	ID number
41	ID total (ID register 1)
42-46	ID registers 2 through 6
51-66	Memory registers 1 through 16
84-90	Print Labels 84 to 90 (see parameters 84 to 90)

**Print Format Design Example**

EXAMPLE PRINT:

	111111111222222222233333333334			
COLUMN	1234567890	1234567890	1234567890	1234567890
LINE				
1				
2				
3		GROSS	54785 LB	
4		TARE	12451 LB	
5		NET	42243 LB	
6				
7		TIME 03:45 PM	DATE 05 AUG 1999	

EXAMPLE FORMAT DESIGN WORKSHEET:

Page:1	Item Description	Line No.	Column	Item No.
E1	Gross Weight	3	4	5
E2	Tare Weight	4	4	6
E3	Net Weight	5	4	7
E4	Time and Date	7	1	10
E5	End of Print	0	0	0

NOTE: A zero in the Line No column terminates printing. Use zero only after all required information has been entered. The maximum number of entries is 16. If the 16<sup>th</sup> entry is used, a line number 0 is not required.

**Default Print Formats**

The print formats (PAGES) are initialized to the following factory settings when the DT200 is initialized.

Page 1	Item Description	Line No.	Column	Item No.
E1	The Displayed Weight	1	1	18
E2	End of Print	0	0	0

Page 2	Item Description	Line No.	Column	Item No.
E1	Gross Wt. (primary units)	3	5	5
E2	Tare Weight (primary units)	4	5	6
E3	Net Weight (primary units)	5	5	7
E4	End of Print	0	0	0

**Format Design Worksheets**

<b>Page</b>	<b>Item Description</b>	<b>Line No.</b>	<b>Column</b>	<b>Item No.</b>
E1				
E2				
E3				
E4				
E5				
E6				
E7				
E8				
E9				
E10				
E11				
E12				
E13				
E14				
E15				
E16				

<b>Page</b>	<b>Item Description</b>	<b>Line No.</b>	<b>Column</b>	<b>Item No.</b>
E1				
E2				
E3				
E4				
E5				
E6				
E7				
E8				
E9				
E10				
E11				
E12				
E13				
E14				
E15				
E16				

## Function 66 Set Time and Date

---

Use function 66 to set the time and date. Entering 19 can display the time and date when the meter is in the idle mode. Date will be printed in a Y2K compliant four-digit year.

1. Hold the CLEAR key down and press the ENTER key to enter the configure mode.
2. Enter CFG 66. The DT200 prompts “t”. Enter the time using 5 digits. The last digit should be 0 for AM, 1 for PM, or 2 for 24-hour time.
3. The DT200 prompts “D”. Enter the date using 6 digits in the format MMDDYY.

## Function 67 Display Operation Parameters

---

Use function 67 to view operation parameters. This function allows viewing the parameters when the password is not available.

1. Hold the CLEAR key down and press the ENTER key to enter the configure mode.
2. Enter CFG 67. The DT200 prompts “PAR xx” where xx is the currently selected parameter number. Press the ENTER key to view the parameter data or enter a parameter number to view.
3. Press the CLEAR key to exit function 67.

## Function 68 Print Operation Parameters

---

1. Hold the CLEAR key down and press the ENTER key to enter the configure mode.
2. Enter CFG 68. The DT200 prompts “Print”. Press the ENTER key to print the operation parameters or press the CLEAR key to exit without printing.

## Function 69 Diagnostic Tests

---

1. Hold the CLEAR key down and press the ENTER key to enter the configure mode.
2. Enter CFG 69. The DT200 prompts “diA xx” where xx is the currently selected test number. Enter a test number or press the ENTER key to use the displayed number.
3. The DT200 begins the selected test. Press the CLEAR key when the test is complete.

Test #	Hardware Tested	Description
1	Serial Com. Port 1	Display input data.
2	Serial Com. Port 1	Display input error count.
3	Serial Com. Port 1	Transmit data.
4	Serial Com. Port 2	Display input data.
5	Serial Com. Port 2	Display input error count.
6	Serial Com. Port 2	Transmit data.
7	Parallel Port	Transmit data.
9	Ram Memory	Test memory for errors.
10	Display	Turn on all LED's segments.
11	Configuration	Print the EAROM configuration data.



12	Serial Com. Port 1	Transmit/Receive loop-back test.
13	Serial Com. Port 2	Transmit/Receive loop-back test.
14	Serial Com. Port 3	Display input data
15	Serial Com. Port 3	Display input error count.
16	Serial Com. Port 3	Transmit data.

See section: **Diagnostic Tests** for more information on each test.

## **Function 70 Initialize Operation Parameters to Factory Defaults**

---

Use function 70 to reset the DT200's operation parameters to their factory default values. This function is used to reset the DT200's eeprom when a new EPROM program is installed. Do NOT use this function unless you are ready to begin installation from the beginning.

1. Hold the CLEAR key down and press the ENTER key to enter the configure mode.
2. Enter CFG 70. The DT200 prompts, "rESet". Press the ENTER key to reset operation parameters or press the CLEAR key to exit without changing the operation parameters.
3. **NOTE:** enter 10809 when the display prompts, "rESet" to reset the calibration factors to the factory defaults.

## **Function 71 Configure Event Monitor**

---

Use function 71 to enter setpoint data into the Event Monitor. See the "Scale Basic / Event Monitor" manual for more information on the event monitor parameters.

1. Hold the CLEAR key down and press the ENTER key to enter the configure mode.
2. Enter CFG 71. The DT200 prompts "Eno". Enter the Event number to be modified.
3. The DT200 prompts "P0 xx" where P0 is parameter 0 and xx is the current value of parameter 0. Enter new data for P0 or press the ENTER key to use the displayed data.
4. Use the UNITS key (↓) or the PRINT key (↑) to scroll through the parameter numbers. Press the CLEAR key to exit from the current Event number. Press the CLEAR key again to exit from event monitor data entry.

## **Function 72 Scale Basic Function Editor**

---

Use function 72 to create or modify Scale Basic functions. See the "Scale Basic / Event Monitor" manual for more information on Scale Basic functions.

1. Hold the CLEAR key down and press the ENTER key to enter the configure mode.
2. Enter CFG 72. The DT200 prompts "Fn". Enter the function number to be modified.
3. The DT200 prompts "0- xxx" where 0- is entry zero, and xxx is the current value for entry zero. Enter new data for 0- or press the ENTER key to use the displayed data.

4. Use the UNITS key (↓) or the PRINT key (↑) to scroll through the entry numbers.  
Press the CLEAR key to exit from the Function Editor.

### **Function 73 Initialize Function Memory**

---

The initialize function erases function memory and setpoint monitor memory, and initializes all parameters with password level 1 or 2.

Function 73 prompts “rs Fn” . Press the Enter key to initialize only or enter a number below to activate a built in program.

1. Fill to Setpoint.
2. Checkweigh: Over/Between/Under
3. Weigh-in / Weigh-out
4. Axle Weigh – Short Scale
5. Axle Weigh – Long Scale
6. ID Tare and Total
7. Peak Hold

### **Function 74 Configure Timers**

---

The display prompts “tr” when function 74 is activated. Enter the timer number to be modified (1 to 5) then press the ENTER key. The first parameter (L) is the time length in tenths of a second. The second parameter (Fn) is the function number to be executed when the timer times out.

### **Parameter 76 Debug mode for Event monitors and Scale Basic**

---

The Debug mode is used to ‘debug’ event monitors and scale basic functions. Enter a 1 to activate debug mode, enter a 0 to disable debug mode. When debug mode is enabled Scale Basic functions ‘single step’. The subroutine stack level and the Function number are displayed when entering a function. Example: “0 F12”. Press the ENTER key to begin execution of the function. The instruction address and instruction code are displayed. Example: “21 255”. Continue to press the ENTER key to step thru the program. NOTE: the first step displayed for all scale basic functions is a GOTO (244).

### **Function 78 Initialize ID memory**

---

Use function 78 to initialize id memory after it has been corrupted. The ID memory becomes corrupted when power is lost (when battery backup is disabled) or when the battery is allowed to discharge below 2 volts.

### **Parameters 91, 92, 93: Serial Port 3**

---

Serial Communications Port 3 receives weight data from a weight indicator. The mode, baud rate, and format of com. port 3 must be the same as the weight indicator’s settings.

**Parameter 91 Serial Port 3 Mode (4 [8 data bits, no parity])**

Enter the mode number from the table below to select the mode parameter in the mode description column.

Mode Number	Mode Description
1	7 data bits, no parity
2	7 data bits, even parity
3	7 data bits, odd parity
4	8 data bits, no parity
5	8 data bits, even parity
6	8 data bits, odd parity

**Parameter 92 Serial Port 3 Baud Rate (1 [9600 baud])**

Enter a baud number from the table below to select a baud rate from the description column. (\*HS baud rates for the 100 samples per sec version only).

Baud Number	Baud Description
1	9600 Baud
2	4800 Baud
3	2400 Baud
4	1200 Baud
5	600 Baud
6	300 Baud
7	19200 Baud

**Parameter 93 Serial Port 3 Format**

Enter the indicator number from the table below to select a weight indicator.

Indicator no.	Indicator Model
1	Condec
2	AND
3	Cardinal 738
4	OHAUS
5	Toledo 8142

# Diagnostic Tests

---

The DIAGNOSTIC TESTS are accessed using configuration function 69. Hold the CLEAR key down and press the ENTER key. The display prompts “CFG xx” where xx is the currently selected parameter. Enter 69 and press the ENTER key to access the DIAGNOSTIC TESTS.

The display prompts “diA xx” where xx is the last selected diagnostic function. Select a test number from the table below. Enter the test number and press the ENTER key.

## Table of Diagnostic Tests

---

Test No.	Hardware Tested	Description
1	Serial Com. Port 1	Display input data.
2	Serial Com. Port 1	Display input error count.
3	Serial Com. Port 1	Transmit data.
4	Serial Com. Port 2	Display input data.
5	Serial Com. Port 2	Display input error count.
6	Serial Com. Port 2	Transmit data.
7	Parallel Port	Transmit data.
8		
9	Ram Memory	Test memory for errors.
10	Display	Turn on all LED's and display segments.
11	Configuration	Print the EAROM configuration data.
12	Serial Com. Port 1	Transmit/Receive loop-back test.
13	Serial Com. Port 2	Transmit/Receive loop-back test.
14	Serial Com. Port 3	Display input data
15	Serial Com. Port 3	Display input error count.
16	Serial Com. Port 3	Transmit data.

### Diagnostic Test 1: Serial Com Port 1 - Display Input Data

### Diagnostic Test 4: Serial Com Port 2 - Display Input Data

### Diagnostic Test 14: Serial Com Port 3 - Display Input Data

---

This test displays serial data as it is received by serial communications port 1, 2, or 3. The numeric display has limited alpha display capability, however numeric and some alpha characters are legible. If all data being received is unintelligible, the baud rate is probably incorrect. If nothing is displayed on the display, then check the following:

1. RS232/Current loop switch on the main circuit board (com. port 1).  
RS232/RS485 jumper on the main circuit board (com port 2).
2. Cabling between the communicating units.
3. Make sure the sending unit is actually sending data.

Press the CLEAR key to exit the diagnostic test.

**Diagnostic Test 2: Serial Com Port 1 - Display Errors**  
**Diagnostic Test 5: Serial Com Port 2 - Display Errors**  
**Diagnostic Test 15: Serial Com Port 3 - Display Errors**

---

This test displays the number of framing and parity errors that are detected in the input data stream. The error count is set to zero when entering this test. New errors are displayed as “PxxFxx” where Pxx is the number of parity errors and Fxx is the number of framing errors. If the error count exceeds 99, the display will remain at 99. Press the CLEAR key to exit the diagnostic test.

**Diagnostic Test 3: Serial Com Port 1 - Transmit Data**  
**Diagnostic Test 6: Serial Com Port 2 - Transmit Data**  
**Diagnostic Test 16: Serial Com Port 3 - Transmit Data**

---

This test transmits data out of serial communications port 1. The display prompts: “OUT 0”. Press the ENTER key to send data. Serial Port 1 transmits “1234567890ABCDEF” and prompts “OUT 1” to indicate that 1 transmission has occurred. Press the ENTER key again or press the CLEAR key to exit diagnostic test 3.

NOTE: If the error message “Er CtS” appears, the data cannot be transmitted because the handshake signal, clear-to-send (TB1 pin 7), is low or not connected. If clear-to-send is not used jumper it to data-terminal-ready (TB1 pin 4)

**Diagnostic Test 10: Lamp Test**

---

This test turns on all the LED displays and numeric display segments. Replace any LED or display that does not illuminate. Press the CLEAR key to exit diagnostic test 10.

**Diagnostic Test 11: Print the EAROM Configuration Table**

---

This function sends the contents to the EAROM configuration memory to the printer. Use this function to document your setup of the when installation is complete.

**Diagnostic Tests 12 & 13: Loop Back Tests**

---

These tests are used by the factory to test the serial ports transmit and receive functions. Transmit and receive lines must be jumpered together and the clear-to-send must be jumpered to data-terminal-ready for this test.

# Troubleshooting

The following table describes the probable causes to some problems you may encounter. Most problems can be resolved by using the information provided in the table.

## Problems And Probable Causes

Problem	Probable Causes
Printer does not print (serial RS232)	<ul style="list-style-type: none"> <li>* Cable connection problem or invalid pin connections.</li> <li>* Baud rate and format on serial port 1 does not match printer. Printer is not ready or it is busy. Check CTS signal TB1 pin 7. This signal must be high in order to transmit. Jumper pin 8 of TB1 to pin 7 of TB1 CTS/RTS.</li> <li>* Transmitter/receiver IC damaged (U7 MC145406).</li> </ul>
Continuous output does not update	<ul style="list-style-type: none"> <li>* “TX CONTINUOUS” disabled (configuration Parameter 28)</li> <li>* Cable connection problem or invalid pin connections.</li> <li>* Baud rate and format on serial port 2 does not match receiver.</li> <li>* Transmitter/receiver IC damaged (U7 MC145406).</li> </ul>
Input port 1 not working	<ul style="list-style-type: none"> <li>* Baud rate and format on serial port 1 does not match host.</li> <li>* Cable connection problem or invalid pin connections.</li> <li>* Internal switch SW1 (CL/RS232) not set properly for input type.</li> <li>* RS232 transmitter/receiver IC damaged (U7 MC145406).</li> <li>* Current loop receiver IC damaged (U4 4N36).</li> </ul>
Input port 2 not working Desktop 10108 Board has RS232 or RS485. Stainless 10114 Board has RS232 or CL.	<ul style="list-style-type: none"> <li>* Baud rate and format on serial port 2 does not match host.</li> <li>* Cable connection problem or invalid pin connections.</li> <li>* Internal jumper SW2 (RS232/422/485/CL) not set properly.</li> <li>* RS232 transmitter/receiver IC damaged (U7 MC145406).</li> <li>* RS422/485 transmitter/receiver IC damaged (RS422 {U11 75176} RS485 {U14 75176}).</li> <li>* Current loop receiver IC damaged (10114 board U23 4N36).</li> </ul>
Input port 3 not working Desktop 10108 Board has RS232 or CL. Stainless 10114 Board has RS232 or RS485.	<ul style="list-style-type: none"> <li>* Baud rate and format on serial port 3 does not match host.</li> <li>* Cable connection problem or invalid pin connections.</li> <li>* Internal jumper SW4 (RS232/485/CL) not set properly.</li> <li>* RS232 transmitter/receiver IC damaged (U15 MC145406).</li> <li>* RS422/485 transmitter/receiver IC damaged (RS422 {U10 75176} RS485 {U14 75176}).</li> <li>* Current loop receiver IC damaged (10108 U4 4N36).</li> </ul>
“Er CtS” error message.	<ul style="list-style-type: none"> <li>* Cable connection problem. Check CTS signal TB1 pin 7. This signal must be high in order to transmit. Jumper to pin 8 of TB1.</li> <li>* Printer is not ready or it is busy.</li> <li>* Transmitter/receiver IC damaged (U6 - MC145406).</li> </ul>
“Err 13” error message (Printer Error)	<ul style="list-style-type: none"> <li>* This error occurs when the parallel output has been selected for printing and the printer is busy, a printer fault has occurred, or there is a problem with the cable.</li> </ul>



## Error Messages

---

Error	Description
Err 0	Power on zero error. See parameter 20.
Err 1	Keyboard error. Occurs during power up while a key on the keyboard is being pressed or one of the remote switch inputs is activated.
Err 2	Restart Trap. The microprocessor accessed nonexistent memory location. Usual cause is A/C power “glitch” or static electric discharge.
Err 3	Watchdog Time-out. The weight display has not been updated within the watchdog time-out period. Usual cause is A/C power glitch or static electric discharge.
Err 4	Battery Error. Battery voltage level was below 2 V when the DT200 was powered off.
Err 5	Earom memory error. A checksum error has occurred when reading the configuration earom memory. Check calibration parameters and rewrite the earom memory. If error continues, replace earom (U13)
Err 5.1	Earom Time-out, unable to write to the earom memory.
Err 6	Ram memory error. A ram memory error has occurred. Replace U8 if error continues.
Err 7	
Err 8	
Err 9	Count-by error. The entered value is outside the scale count-by set during calibration.
Err 10	
Err 11	
Err 12	
Err 13	Printer busy error. The busy signal (TB4 pin 14) is active (+5v TTL hi).
Err 14	Page Format line length error. The page format output exceeded the maximum line length.
Err 15	The function selected is locked. Switch 2 on the DT200’s circuit board locks and unlocks configuration parameters.
Err 16	Scale Basic Stack Overflow.
Err 18	Referenced an invalid function instruction.
Err 21	ID not found.
Err 22	Scale Basic Prompt error.
Err 23	ID memory full.
Error OL	Scale is over-loaded (above scale capacity).



# Hardware and Wiring

---

This section describes installation and wiring information for the interface ports. There are three bi-directional serial ports and one parallel port with TTL inputs and outputs. The serial ports are used to interface to a weight indicator, a printer and to a host device or PC for continuous output. The parallel port is used to interface to parallel printers and for remote switch input and relay control using the TTL I/O.

## Serial Port 1 Connector - TB 3 (Com1) Desktop & Stainless

---

For RS232 input, set switch SW1 to RS232 position, and for current loop input, set the switch to CL position. **NOTE:** Jumper pin 7 CTS to 8 RTS if unit locks up on "Print".

### Serial Port 1 – TB3

Pin #	Signal Name
1	+5V
2	RS232 TXD (transmit data)
3	RS232 RXD (receive data)
4	DTR (220 ohm to +5V)
5	Ground (GND)
6	Current Loop Transmit
7	RS232 CTS (busy)
8	RS232 RTS (request to send)
9	Current Loop Input -
10	Current Loop Input +

## Serial Port 2 Connector - TB 5 (Com2) Desktop Model 10809 Motherboard

---

The Desktop model uses the 10809 version motherboard for RS232 or RS485 input. Jumper SW2 input jumper to correct setting.

### Desktop Model 10809 Board Serial Port 2 – TB5

Pin #	Signal Name
1	+5V
2	RS232 TXD (transmit data)
3	RS232 RXD (receive data)
4	DTR (220 ohm to +5V)
5	Ground (GND)
6	Current Loop Transmit
<b>Port 2 RS485 TB6</b>	
3	RS485 Transmit -
4	RS485 Transmit +
5	RS485 Receive -
6	RS485 Receive +

## Stainless Steel Wall Mount or Panel mount Serial Port 2 Connector - TB 5

---

The Stainless Steel models use the 10114 version motherboard for RS232 or 20mA Current Loop input. For RS232 or current loop, jumper SW2 input jumper to correct setting.

Pin #	Signal Name
1	Current loop 2 TX
2	RS232 TXD (transmit data)
3	RS232 RXD (receive data)
4	DTR (220 ohm to +7V)
5	Ground (GND)
6	Current loop 2 input +
7	Current loop 2 input -

## Desktop Serial Port COM 3 RS232 DB9 Scale Interface Port

---

### Serial Port 3 – COM3

Pin #	Signal Name
1	No connection
2	RXD (RS232)
3	TXD (RS232)
4	No connection
5	GROUND
6, 7, 8 & 9	No connection

## Stainless Steel Models Serial Port COM 3 TB7 Scale Interface

---

### Serial Port 3 – COM3 TB7

Pin #	Signal Name
1	+5 Volts I/O
2	TXD (RS232)
3	RXD (RS232)
4	DSR Soft 5 Volts 220 Ohm
5, 6 & 7	GROUND

## Stainless Steel Wall Mount or Panel Mount Serial Port 3 RS485/TTL Connector - TB 6

---

For RS232 or RS485, jumper SW4 input jumper to correct setting.

Pin #	Signal Name
1	TTL input 5
2	TTL input 6
3	RS485 TX +
4	RS485 TX -
5	RS485 RX +
6	RS485 RX -
7	Ground (GND)

## Digital/ Parallel Port Connector – TB2 & TB4

---

TTL outputs 1 thru 8 will drive 24ma at TTL low level, and 8ma at TTL hi level. Output 9 is an open collector output with 4.7k-ohm resistor to +5V.



### Digital/Parallel Port – TB2

Pin #	Signal Name
1	TTL Output 1
2	TTL Output 2
3	TTL Output 3
4	TTL Output 4
5	TTL Output 5
6	TTL Output 6
7	TTL Output 7

### Digital/Parallel Port – TB4

Pin #	Signal Name
1	TTL Output 8
2	TTL Output 9
3	TTL Input 1
4	TTL Input 2
5	TTL Input 3
6	TTL Input 4
7	GROUND



## P.C. Board Diagram - Connectors, Jumpers, and Switches



## Sample Cable Drawings




---

### IDS150A/152/160/320




### DT210/IDS550/IDS710/PC (Continuous Output Port)






### Parallel (Centronix) Printer



### Remote Switch Inputs







# DT200 Specifications

---

Display	Vacuum Florescent 8-digit numeric with 6 status indicators.
Keyboard	Sealed keyboard with tactile feel.
I/O Ports	<b>Desktop Models</b> Serial port 1 - RS232 or Cur. Loop. Serial port 2 - RS232 or RS485 Serial port 3 – RS232 9 TTL outputs. 6 TTL inputs.
I/O Ports	<b>Stainless Steel Models</b> Serial port 1 - RS232 or Cur. Loop Serial port 2 - RS232 or Cur. Loop Serial port 3 – RS232 or RS485 9 TTL outputs. 6 TTL inputs.
Watchdog Timer	Fault tolerant operation (212ms).
Power Input	115/220 VAC 50/60 Hz.
Operating Temperature	-10 to 40 degrees centigrade.
Options	Analog output module/Relay module
Programmed from the keyboard or with Ez-link PC software (sold separately)	

# ASCII CHART

---

ASCII	DEC
Null	00
SOH	01
STX	02
ETX	03
EOT	04
ENQ	05
ACK	06
Bell	07
BS	08
HT	09
LF	10
VT	11
FF	12
CR	13
SO	14
SI	15
DLE	16
XON	17
TAPE	18
XOFF	19
DC4	20
NAK	21
SYN	22
ETB	23
CAN	24
EM	25
SUB	26
ESC	27
FS	28
GS	29
RS	30
US	31

ASCII	DEC
SP	32
!	33
"	34
#	35
\$	36
%	37
&	38
'	39
(	40
)	41
*	42
+	43
,	44
-	45
.	46
/	47
0	48
1	49
2	50
3	51
4	52
5	53
6	54
7	55
8	56
9	57
:	58
;	59
>	60
=	61
>	62
?	63

ASCII	DEC
@	64
A	65
B	66
C	67
D	68
E	69
F	70
G	71
H	72
I	73
J	74
K	75
L	76
M	77
N	78
O	79
P	80
Q	81
R	82
S	83
T	84
U	85
V	86
W	87
X	88
Y	89
Z	90
[	91
\	92
]	93
^	94
<-	95

ASCII	DEC
`	96
a	97
b	98
c	99
d	100
e	101
f	102
g	103
h	104
i	105
j	106
k	107
l	108
m	109
n	110
o	111
p	112
q	113
r	114
s	115
t	116
u	117
v	118
w	119
x	120
y	121
z	122
{	123
	124
}	125
~	126
DEL	127